


# Replacement Parts List

## Outer Assembly




Item	Part No.	Description	*RPL
1	235106	HOB	D
2	234398	SIDE PANEL LH	D
3	235290	REAR ELECTRICAL GUARD	D
4	235271	REAR COVER PANEL	D
5	234486	BACK PANEL	D
6	234397	SIDE PANEL RH	D
7	235036	ADJUSTABLE LEG 145-210mm	D
8	234574	DOOR ASSEMBLY	C

* Recommended Parts Level	
RPL	Number of units in service
A	1-5
B	5-10
C	10-50
D	50+

# Replacement Parts List

## Control Panel




Item	Part No.	Description	*RPL
34	233865	BADGE MOFFAT	D
	233867	BADGE BLUESEAL	D
35	228132	TUBE CLIP	B
36	235028	SWITCH	A
37	234135	TIMER	A
38	235212	BUZZER BRACKET	D
39	011794K	BUZZER 240V	A
40	017121	THERMOSTAT	A
41	233887	SWITCH ROTARY ON/OFF	A
42	234402	CONTROL PANEL	D
43	235109	CONTROL PANEL TRIM	D
44	235295	HEAT DEFLECTOR	D
45	234136	INDICATOR LED	A
46	235030	KNOB THERMOSTAT	B
47	233613	KNOB	B
48	235029	KNOB LO-2-3-4-5-HI	B

* Recommended Parts Level	
RPL	Number of units in service
A	1-5
B	5-10
C	10-50
D	50+

# Replacement Parts List

## Oven Racks & Lamp




Item	Part No.	Description	*RPL
25	234048	LAMP ASSY G9 230V Complete	A
26	231814	LAMP	A
27	004595	FAN BAFFLE	D
28	003002	LAMP LENS	B
29	234205	SIDE RACK RH	D
30	234206	BOTTOM ELEMENT GUARD	D
31	233567	WIRE RACK	D
32	233552	THUMBSCREW	B
33	234204	SIDE RACK LH	D

* Recommended Parts Level	
RPL	Number of units in service
A	1-5
B	5-10
C	10-50
D	50+

# Replacement Parts List

## Elements & Fans




Item	Part No.	Description	*RPL
9	013998	FAN ASSY	C
	013998K	FAN ASSY (Up to Lot # 1105999)	C
10	233862	MICROSWITCH	A
11	232775	TERMINAL BLOCK	D
12	026160	TERMINAL BLOCK	D
13	233870	CABLE CLAMP	D
14	026161	CABLE CLAMP	D
15	025400	OVERTEMP THERMOSTAT 360C	A
16	013431	MOTOR 208/240V 50/60HZ	B
17	013432	FAN	B
18	234202	ELEMENT BOTTOM	B
19	235277	ROLLER CATCH STRIKE	B
20	234464	DOOR SEAL	A
21	234462	ELEMENT TOP	B
22	235311	THERMOSTAT	B

* Recommended Parts Level	
RPL	Number of units in service
A	1-5
B	5-10
C	10-50
D	50+

# Replacement Parts List

## Door




Item	Part No	Description	*RPL
30	234579	DOOR HANDLE	C
31	234930	DOOR HINGE KIT (Includes top and bottom hinges )	B
	234752	HINGE PIVOT KIT (Include pivot pin, pivot bush and washer)	B
32	234725	DOOR CATCH BLANKING PLATE	D
33	041045	SCREW 8x3/8" TRUSS HD PHL NP	D
34	234779	INNER GLASS RETAINING CLIP	D
35	234756	DOOR INNER GLASS ASSY	C
36	234767	INNER GLASS PIVOT SPACER	C
38	234580	DOOR ROLLER CATCH	C
39	234818	INNER GLASS LATCHING STUD	D
40	234835	DOME PLUG	D
48	235276	DOOR OUTER GLASS ASSEMBLY	C

* Recommended Parts Level	
RPL	Number of units in service
A	1-5
B	5-10
C	10-50
D	50+

# Replacement Parts List

## Hob Assembly



Item	Part No.	Description	*RPL
23	002920	HOTPLATE ELEMENT 2.0KW	C
24	002888	HOTPLATE ELEMENT 1.5KW	C

* Recommended Parts Level	
RPL	Number of units in service
A	1-5
B	5-10
C	10-50
D	50+